

## Toshiba Combined Controller-Timer. RBC-AMS41E



### Setting Current Date & Time

Hold **SCHEDULE** for 4 seconds. ( setting appears)  
Keep pressing **DAY** until day shows ie today, wed thu etc.  
Use the **TIME** up & down time buttons to adjust to present time.  
Press **SET** to confirm. Clock will now run.

### Setting On & Off Times (referred to as scheduled operations in the manual)

Press **PROGRAM** & Screen flashes.  
Press **DAY** and for convenience, bring to Mon(day)  
Press **SET**.  
Press **UNIT** until PG-01 shows. ( your first program)  
Press **SET**.

Press **TIME** up & down arrows until your required *ON TIME* is displayed.  
Press **SCHEDULE** to set start time – (symbol is clock & 1)  
Press **SET**

Press **UNIT**. PG-02 will appear (your off program)  
Press **SET**  
Press **TIME** up & down arrows until your required *OFF TIME* is displayed.  
Press **SCHEDULE** to set off time – (symbol is clock & 0)  
Press **SET** and then press **PROGRAM**

There should now be a bar line underneath **MON** to indicate that times have been entered.

To set **TUE** etc you can now copy **MON** settings as follows.  
Press **PROGRAM** & Screen flashes.  
Press **DAY** and bring back to **MON**.  
Press **SET**.

\*Press **UNIT** until you see **PG-CP** (programme copy)  
Press **SET**.  
Press **DAY** and select **TUE**.  
Press **SET**. ( MON times have now been copied into TUE) to continue copying go to \*

Press **PROGRAM**.

The times are now entered into the controller.

**NB To activate the timer press SCHEDULE.** ( Flashing clock appears ) Press **SET**.

To deactivate the timer press **SCHEDULE** and then **CL**.